



SPECIFICATION



DWG

PRODUCT NO

ML37Q



Marlowe Quadra
Soft Square
Sconce

Type:	Sconce
Globe type:	G9 LED
Voltage:	110V-220V compatible
Wattage:	5W
Environment:	Indoor
Installation:	Hard Wired


The Marlowe Quadra Soft Square Sconce is a flush-mount architectural wall light featuring a rounded square Milky Onyx backplate and a central frosted glass globe.

Designed to soften strict geometric lines, the continuous, gently curved edges of the backplate serve as a natural canvas to display the stone's unique banding. The Milky Onyx highlights a creamy, semi-translucent white base intertwined with warm, fluid ribbons of amber and gold that appear to shift in depth when illuminated.

Functioning as both a highly refined luminaire and a structural design element, the Quadra provides a soft, diffused ambient glow. Its streamlined profile and versatile power options make it an ideal, scalable fixture for modern corridors, bathroom vanities, and hospitality spaces.


INSTALLATION

STEP 1




- Locate & Mark**
- Hold the hanging base against the wall at the desired height.
 - Use a level to ensure it's straight, then mark screw hole positions.
 - Verify no electrical wires/pipes are behind marked spots
- Connect Wires**
- Important: Confirm power is OFF
 - Feed home wiring through the base's center opening.
 - Secure with wire nuts or terminal blocks. Wrap connections with electrical tape.
 - Tuck wires neatly into the electrical box.

STEP 2




- Drill & Secure**
- Drill holes at marked points using a masonry bit (for concrete/brick) or wood bit (for studs).
 - Insert wall plugs (expansion anchors) if needed.
 - Align the hanging base with holes and fasten using screws. Ensure it's firmly attached

STEP 3



- Attach the Light**
- Align the lamp body with the mounted base.
 - Install the bulb(s) into the socket
 - Use only the recommended bulb type and wattage
 - Secure the lampshade using its locking mechanism

STEP 4



- Restore Power & Inspect**
- Turn power back on at the breaker.
 - Test the light. Check for flickering, unusual sounds, or heat.
 - If issues occur, immediately turn off power and recheck connections.